


Modellszám DMR106 JOB SITE RADIO



Tétel	Cikkszám	Megnevezés	Átala	Menny.	N/O	Opc 1	Opc 2	Megjegyzés
001	SE00000437	WIRE		1				
002	SE00000325	SCREW PTB 3X8(NI)		3				
003	SE00000442	PCB A ASS'Y EUROPE		1				
004	SE00000325	SCREW PTB 3X8(NI)		6				
005	SE00000329	PCB C ASS'Y EUROPE		1				
006	SE09090011	SCREW 1.7		4				
007	SE00000333	POWER BUTTON HOLDER		1				
008	SE00000334	POWER BUTTON		1				
009	SE09090011	SCREW 1.7		5				
010	SE00000336	PRESET BUTTON HOLDER		1				
011	SE00000337	PRESET BUTTON		1				
012	SE00000325	SCREW PTB 3X8(NI)		3				
013	SE00000339	PCB P ANT BAR ASS'Y		1				
014	SE00000325	SCREW PTB 3X8(NI)		2				
015	SE00000239	KNOB LENS HOLDER		1				
016	SE00000193	SCREW 3X10		2				
017	SE00000343	PCB P USB ASS'Y		1				
018	SE09064161	SCREW M4X16		1				
019	SE00000325	SCREW PTB 3X8(NI)		4				
020	SE09064161	SCREW M4X16		1				
021	SE00000347	FRONT CABINET ASS'Y		1				
022	SE09064161	SCREW M4X16		1				
023	SE00000325	SCREW PTB 3X8(NI)		1				
024	SE09064161	SCREW M4X16		1				
025	SE00000351	FRONT BUMPER		1				
026	SE00000160	SCREW PTHE6X47(CR)		4				
027	SE0338PC5Z	FRONT BAR		2				
028	SE00000355	JACK RUBBER COVER		1				
029	SE00000356	JACK COVER		1				
030	SE21B1110A	ROTARY KNOB RING		1				
031	SE00000243	ROTARY KNOB		1				
032	SE09176166	HEX SCREW M6X16		2				
033	SE00000357	BATTERY BUMPER		1				
034	SE00000359	REAR BUMPER		1				
035	SE09176166	HEX SCREW M6X16		2				
036	SE00000362	LOCKER COVER		1				
037	SE00000364	LOCKER FIXER PIN 73.5MM		1				
038	SE00000365	LOCK HINGER		1				
039	SE00000367	BATTERY COVER		1				
040	SE00000369	LOCKER FIXER PIN 64.5MM		1				
041	SE00000325	SCREW PTB 3X8(NI)		2				
042	SE00000371	BATTERY COVER PACKING		1				
043	SE0307PC5Z	BACK UP BATTERY COVER		1				
044	SE00000176	SCREW PTHE6X20(CR)		1				
045	SE00000177	HANDLE HOLDER(R)		1				
046	SE00000179	HANDLE		1				
047	SE00000180	HANDLE HOLDER (L)		1				
048	SE00000176	SCREW PTHE6X20(CR)		1				

Tétel	Cikkszám	Megnevezés	Átala	Menny.	N/O	Opc 1	Opc 2	Megjegyzés
049	SE09176166	HEX SCREW M6X16		1				
050	SE00000184	SPRING		2				
051	SE09994007	STEEL BALL		2				
052	SE023PC020	EVA 25X18X5.5		1				
053	SE00000445	SCREW PTB 3X45(NI)		1				
054	SE09994007	STEEL BALL		2				
055	SE00000184	SPRING		2				
056	SE09176166	HEX SCREW M6X16		1				
057	SE00000187	HANDLE SUS-PLATE (R)		1				
058	SE00000445	SCREW PTB 3X45(NI)		1				
059	SE00000192	HANDLE SUS-PLATE(L)		1				
060	SE00000392	REAR CABINET		1				
061	SE00000395	RUBBER ANT 88-108(BLK)		1				
062	SE00000398	ROD ANT PACKING		1				
063	SE00000396	ROD ANT TERMINAL		1				
064	SE00000325	SCREW PTB 3X8(NI)		1				
065	SE023PC020	EVA 25X18X5.5		1				
066	SE00000403	DC RUBBER COVER		1				
067	SE00000404	SCREW PTHE 3X14(CR)		1				
068	SE021PC030	BATTERY COVER LOCKER		1				
069	SE00000406	SPEAKER PACKING		1				
070	SE00000407	SPEAKER(R)		1				
071	SE00000408	SPEAKER PANEL ASS'Y		1				
072	SE024J9040	PACKING		4				
073	SE9076146A	HEX SCREW M6X14		4				
074	SE9076146A	HEX SCREW M6X14		4				
075	SE024J9040	PACKING		4				
076	SE00000408	SPEAKER PANEL ASS'Y		1				
077	SE00000438	SPEAKER (L)		1				
078	SE00000406	SPEAKER PACKING		1				
079	SE00000416	TERMINAL E (B)		1				
080	SE00000325	SCREW PTB 3X8(NI)		2				
081	SE00000200	TERMINAL C		1				
082	SE00000325	SCREW PTB 3X8(NI)		2				
083	SE00000420	PCB B BATTERY SWITCH ASS'Y		1				
084	SE00000325	SCREW PTB 3X8(NI)		1				
085	SE00000422	SPEAKER HOLDER		1				
086	SE00000423	PCB B AUX IN 2 ASS'Y		1				
087	SE00000193	SCREW 3X10		2				
088	SE00000199	SILICON RUBBER WASHER		1				
089	SE00000325	SCREW PTB 3X8(NI)		1				
090	SE00000199	SILICON RUBBER WASHER		1				
091	SE00000325	SCREW PTB 3X8(NI)		1				
092	SE00000422	SPEAKER HOLDER		1				
093	SE00000430	SWITCH KNOB		1				
094	SE00000431	BATTERY SWITCH ASS'Y		1				
095	SE00000325	SCREW PTB 3X8(NI)		2				
096	SE00000433	PCB B DC JACK ASS'Y		1				

